

We Build Custom Air Conditioning Hose

We sell all the parts you need to build custom R-134a hose yourself. But if you'd rather not handle it, give us a call and we'll build it for you.



Should I replace an OEM cable with Cablecraft?

The short answer is "Yes, because Cablecraft cables are simply the best, OEM or aftermarket." Whether you want one of our off-the-shelf standard cables, or a cust-built cable for your specific application, you will be surprised at the durability, ease of use and range of conditions you can use these cables under.

Strobe	Volt	Flash	Joules	Notes
3421	24	Single	11.5	Euro "A" approval
4261	12/24	Double	12	Night/day self-adjust
3318	12/110	Single	1.5	



#4261



#LDA50



#HDS54



#SWM43



#3421



#112/#370



#230/#250



#3318

Backup Alarm	Volt	Decibel
LDA50	12	97
112	12/24	97/102/112
230	12	97
240	12/24	97
250	12/24	102
370	12/24	97/107
Backup Alarm Switch	Amp	Position
HDS54	5	NO
SWM43	5	Adjustable: NO or NC

We offer thousands of strobes and alarms. Call us for a full Preco catalog.



Budget Auto Parts

Manual Air Bags

Why pay extra for fancy automatic air bags you'll almost never use? These manual air bags provide all the protection you need in most accidents.*

* "Accident" must occur under 10 mph. Manual Air Bag must be properly inflated to 75 PSI to operate correctly. Failure to properly inflate releases manufacturer from all liability. Not for use with children or pregnant women. Warning: bag may contain lead, asbestos, and trace amounts of peanuts.

